



## STORAGE INSTRUCTIONS

### SeIRO<sup>®</sup> SPIRAL ELEMENTS

#### A. SHELF LIFE

The elements leave the factory stored in Benzalkonium Chloride solution. From the date of shipment, the element shelf life in the original packaging is one year when stored in Benzalkonium chloride. This assumes that the sealed bags have not been opened or damaged and the conditions shown in Sections B&C are met.

#### B. HANDLING

1. The boxes should not be dropped or crushed.
2. The elements should be stored horizontally.

#### C. NEW ELEMENT STORAGE CONDITIONS

1. Keep the elements in their original packaging.
2. Store indoors out of direct sunlight.
3. Do not allow the elements to freeze and they should be kept at less than 40°C (104°F).
4. The preferred long-term storage temperature range is 10°C to 30°C (50 to 86°F), at relative humidity below 70%.

#### D. USED ELEMENT STORAGE SOLUTION

1. **Short-term shut-down (up to 24 hours):** Elements should be thoroughly cleaned and left in water at 5-25°C (41 to 77°F).
2. **Mid-term shut-down (up to 30 days):** Elements should be thoroughly cleaned. The vessels should then be filled with one of the following chemicals:
  - a. KOCHKLEEN<sup>®</sup> 180 (or equivalent) at pH 3-4
  - b. 2,000 ppm solution of sodium bisulfite at 5-25°C and pH 3-4
3. **Long-term shut-down (30 days or longer):** Elements should be thoroughly cleaned. Follow the same procedure as the mid-term storage, but replace the storage solution every 30 days.

#### E. POST-STORAGE CLEANING PROCEDURE (MID AND LONG-TERM ONLY)

All elements should be cleaned according to KMS' recommended pre-startup procedures prior to restarting the system on production.

---

Koch Membrane Systems, Inc., [www.kochmembrane.com](http://www.kochmembrane.com)

**Corporate Headquarters:** 850 Main Street, Wilmington, Massachusetts 01887-3388, US, Tel. Toll Free: 1-888-677-5624, Telephone: 1-978-694-7000, Fax: 1-978-657-5208  
**European Headquarters:** Koch Chemical Technology Group Ltd., Units 3-6, Frank Foley Way, Stafford ST16 2ST, GB, Telephone: +44-178-527-2500, Fax: +44-178-522-3149

• Aachen DE • Lyon FR • Madrid ES • Milan IT • Wijnegem BE • Beijing & Shanghai CN • Mumbai & New Delhi IN • Melbourne & Sydney AU • Singapore • Sao Paulo BR • Dubai UAE

For related trademark and patent information, visit [www.kochmembrane.com/legal](http://www.kochmembrane.com/legal)

Koch Membrane Systems, Inc. is a Koch Chemical Technology Group, LLC company.

© 2015 Koch Membrane Systems, Inc. All rights reserved worldwide.

01/15 Rev 15-1